

Boat Size & Venting Chart

Find The Right Size Shrink Wrap For Your Boat

Film Size	Sq. Ft	Boat Length	Beam	# of Boats	# of Vents	Description
12' x 175'	2100	0'-16'	up to 7'	8	4	Works well for finishing boats & boats with low windshields
14' x 150'	2100	14'-19'	up to 8'	6	4	Great for runabout with full windshields
17' x 120'	2040	17'-24'	up to 8.5'	4	6	Excellent for pontoon boats and cuddy cabin cruisers
20' x 100'	2000	25'-29'	up to 8.5'	3	6	Good for express cruisers
24' x 115'	2760	25'-29'	up to 9'	3	6	Superb for express cruisers with arches or small flybridges
26' x 100'	2600	28'-31'	up to 10'	2	8	Very little waste on wider, taller flybridge boats under 32'
32' x 100'	3200	30'-38'	up to 11'	2	10	Super for wide and tall flybridge boats with an arch
40' x 100'	4000	44'-60'	up to 16'	1	12	Covers very large boats with arches and bridges with one piece of wrap
50' x 100'	5000	60'+	16'+	1	16	Excellent one piece coverage for the largest of boats with multiple levels, arches & bridges

*These sizes are approximate - each boat must be measured to assure that the proper size wrap is used.
Always over ventilate and use the Shrinkfast® 998 for best results.